

Fitting of Durite PSS Kit Extension Bracket 0-870-79

The blocks are 25mm wide so can be added to in order to meet different length requirements. The kit is supplied with 110mm bolts to make a 100mm extension and 60mm bolts to make a 50mm extension. If a different length is required then differing length bolts will be required.

1. Arrange the blocks with the rounded section all at the front and insert the bolts through the bolt holes. They can be inserted either way through the blocks but care must be taken if inserting them towards the mounting block that they do not protrude beyond the edge of the mounting block causing issues when mounting the unit to the vehicle.



2. With the bolts through the blocks the camera mounting bracket can be added to the end of the block stack and the nuts and washers applied.



3. The plastic covers can be fitted in the usual way onto the camera mounting bracket.



4. Here is a picture of the 50mm extension in place using the 60mm bolts.



5. The four holes in the mounting ears are to be used for the mounting of the assembly onto the vehicle. (n.b. the image only shows two holes but this is changed for production).