

Adjust image orientation on DX / DL1 DVR


Enter DVR Menu by pressing Set up on remote

User name admin
Password eagle

Login screen as below



Then Using the arrows select Setup menu as per image below



Then Select the Surveillance menu from top bar

Now Under Live View Tab at the side then in Preview Select Image Setup.



Once in image set up you need to select the channel that need adjusting



Once you have the correct channel selected use the horizontal / vertical flip buttons to get image in correct orientation



When image is correct you can then save and exit the menus

