

## Pairing Magnetic wireless camera to receiver

1. Connect the Receiver module to a wired display or DVR Camera Input.
2. Connect the power feed for the receiver module Red +12/24V, Black Ground. On the display you will get the no signal message as the camera is not paired with the receiver yet.



3. With the receiver module powered up press and hold the red button until the LED Flashes Red / Blue and the display indicates Pairing mode.



4. Now Press the power button on the camera to power on the operation LED should be Green.



5. then press button twice then the operating LED should turn Blue indicating it's in pairing mode.



6. After a few seconds the Camera Image will come through onto the Display and the operating LED will turn Green on the camera and the LED on the Receiver module will go to solid Blue.



7. Now the camera is paired with the camera so can be powered on / off as needed