



- Buzzer
- Right Indicator feed (Purple wire)
- Reverse Feed (Brown & White wire)
- Left indicator feed (purple wire)

Ignition Power Peripheral

360 KIT ECU

Ground Cameras IR Extension port

360 KIT Driver Switch

360 kit IR Sensor

Ignition Power

Touchscreen DVR (0-775-54)

Camera 5 Camera 1 Camera 4 Camera 2 Camera 3 Ground

360 kit camera harness

0-775-23

0-775-23

0-775-23

0-775-23

(0-775-84) Y Split cable cctv

Left

360 KIT CAMERA

(0-775-84) Y Split cable cctv

Front

360 KIT CAMERA

(0-775-84) Y Split cable cctv

Right

360 KIT CAMERA

(0-775-84) Y Split cable cctv

Rear

360 KIT CAMERA



						Prj: 0-870-75	Sheet nb: 1 of 1
						Prj nb: 360 Birds Eye system	Desg. by: D Dalmon
A	15/02/2023			Open		Title: Wiring Diagram	
Rev.	Date	Description	Appd. by	Status			

