


Permanent _____

Ignition _____

Auxiliary _____

0-876-95 Panic Button

0-876-93 RS485 Adaptor



To DX/DL 1 DVR serial I/O port

Ground

Prj:	panic button dx_d11	Sheet nb.	1 of 1
Prj nb:	0-876-95 + 0-876-93	Desg. by:	D Dalmon
Rev.	Date	Description	Appd. by
A	13/07/2023		Open
Title:			Wiring Diagram

